

FITTING INSTRUCTIONS

Nailed Floor




1 • The strip of flooring must be fitted parallel to the largest side of the room and cross-ways to the direction of the wooden battens.

Allow a maximum of 45 cm between each batten, which are either:

a - fixed to the subfloor by glue or cement (pay attention to drying time)

b - not fixed but placed on a fibre based underlay. This system is quicker and increases sound insulation



2 • Lay the first row, not forgetting the expansion gap all around the edge.



3 • Nail down at an angle through the tongues (45 or 50 mm flat nails) using a nail punch to avoid obstructing the position of the following boards.



4 • Fix the skirting-board in place without exerting any pressure on the wood floor. The flooring must never be fixed against obstacles (eg : pipes, doorway, etc...)

