



Difficulty: 3/5

Tools: - Chevron Panaget wood flooring, Isol 30 Underlay, Skirting Boards, Masking Paper Tape, Shims, Tape Measure, Pencil, Square Ruler, Circular Saw, Cutter, Hammer, Pullers, Gloves, Presto Gun Glue, Expansion Shims, Cloth.

STEPS:

- 1/ Unroll the insulating underlay with polyane (e.g. Isol 30) on the flat and dry surface.
- 2/ The strips are taped together edge to edge and go up to the base of the skirting boards.
- 3/ Open two or three packages. Separate the right and left planks of your chevron wood floor by mixing the shades.
- 4/ Draw the center line of the room. Generally, the spans are placed in the center line of the front door or on the center line perpendicular to the largest light entrance.
- 5/ Fit 3 pairs (3 left / 3 right) by gluing the groove end and length to avoid too much slippage when assembling the boards.
- 6/ Place the upper point of the reference span resting on the wall (with a wedge).
- 7/ Leave this for 1h so that the reference span is fixed.
- 8/ Continue laying the pairs in the span until the end of the axis, remembering to glue the grooves.
- 9/ Regularly check the alignment of the axis and the junctions between the chevrons.
- 10/ Once the end of the axis is reached, resume the installation by developing the spans on each side of the reference span.

Fill reserves along a wall.

- 1/ Measure the remaining space taking into account the expansion play.
- 2/ Assemble 3 planks and record the measurement of the remaining space.
- 3/ Cut the planks to size.
- 4/ Glue the groove of the plank.
- 5/ Lay the plank so as to fill the gap against the wall. Fit them to adjacent planks using a pull bar.

Fill in the ends of axes.

- 1/ Measure both sides of the angle and the perpendicular bisector.
- 2/ Assemble 6 planks. Transfer the measurements and draw a cut line.
- 3/ Cut out the triangle with a circular saw.
- 4/ Glue the groove and fit the triangle with a pull bar.

Remove the wedges 24 hours after installation.

- 11/ The expansion joints are covered using the appropriate accessories (skirting, radiator collar, threshold bar, etc.).



See the video tutorial

www.panaget.com

3 rue d'Orgères 35230 Bourgbarré - France
TEL | 0033 (0)2 99 05 77 77
FAX | 0033 (0)2 99 57 73 55



Scotch sur parquet interdit
No tape